




4Z Mill



Air inlet shown max head room



Extension plate provided
 Locate / raise millhead & slide up +2 or +4 inch
 Locate / lower millhead & slide down -2 or -4 inch